Smart Cleaner MU/LC Instruction Manual [18038]

Thank you for choosing the Smart Cleaner MU/LC. The Smart Cleaner MUILC is a high-performance device designed for cleaning the ferrule end faces of MU/LC connectors. Carefully read this instruction manual befor using this device. Please keep this instruction manual for future reference.

1. Safety precautions

Though our device is deemed safe, improper usage or handling can still inflict injury to others.

Smart Cleaner MU/LC is designed to clean MU and LC connectors only. It is not liable for damage caused in attempt to apply this device to other applications.

2. Notes on usage

Do not attempt to disassemble as this can cause damage to the device.

Do not re-use cleaning cloth as this will eliminate its cleaning ability.

Do not touch the cleaning cloth as this will cause contamination.


Do not pull the cleaning cloth, use only the device body.

Do not use this cleaner when the cloth is empty, as this can cause damage to the connector.

3. Notes on storage for extended periods

Do not expose device to direct sunlight, high temperature or high humidity. The cover on the guide cap should be closed at all times when device is not in use.

4. Device construction




No.	Part Name	Function
Α	Tip	Lead the cleaning cloth to the optical connecter end face.
В	Nozzle	Lead tip to the optical connecter end face.
С	Lock Button	Push the button to extend and contract the nozzle.
D	Outer Shell	Push the outer shell to clean the connector.
E	Guide Cap	Acts as dust cap or cleaning adapter for connector plug.
F	Indicator	Provides indication of remainig cleaning cloth

5. Applications


<Connector inside adaptor>

1. Remove Guide Cap from the device.

<Connector plugs alone>




2. Insert tip of cleaner into MU/LC Adaptor.




Standard Mode Extended Mode
drawing shows only LC, but this production
can clean MU too.

2. Insert MU/LC connector into the Guide Cap.



3. Push the Outer Shell to start cleaning the MU/LC connector end face. A "click" sound indicates end of cleaning process. Close the cover after use.




careful not to slant the Smart Cleaner MU/LC while inserting into the adapter.

Do not overly exert force during insertion as this may cause damage to both the connector and the Smart Cleaner MU/LC.

If pushing Outer Shell is inhibited, remove Smart Cleaner MU/LC from adapter and ensure that there is no sizeable debris inhibiting the cleaning process.

3. Push the Outer Shell to start cleaning the MU/LC connector end face. A "click" sound indicates end of cleaning process. Close the cover after use.



careful not to slant the Smart Cleaner MU/LC while inserting into the adapter.

Do not overly exert force during insertion as this may cause damage to both the connector and the Smart Cleaner MU/LC.

If pushing Outer Shell is inhibited, remove Smart Cleaner MU/LC from adapter and ensure that there is no sizeable debris inhibiting the cleaning process.

